

### SST-PB3-CLX-RLL 模块 DP 从站设置

#### 参考资料:

**715-0102\_SST-PB3-CLX-RLL\_User\_Reference\_Guide.pdf**------- Edition 1.1 (第 10 章 P135-145 为有关从站配置的详细说明) 下载地址: www.mysst.com/download

设备名称	描述	
A-B ControlLogix 系统	CPU L5555(v15)+Ethernet 通讯模块	
SST-PB3-CLX-RLL	Woodhead Profibus DP 主/从通讯模块	
	<ul> <li>主要特点:</li> <li>✓ 可插在任意的槽位;</li> <li>✓ 支持主站 DP V0/V1 功能;</li> <li>✓ 可在支持主站同时,设置为 DP V0 从 站;</li> <li>✓ 支持所有标准 DP 通讯速率;</li> <li>✓ 提供 RLL 功能 (Remote Link Library);</li> </ul>	

#### 相关软硬件和资料

软件名称	版本
SST Configuration Tool	3.11.0 以上
RSLogix5000	15.01
RSLinx	2.50

本说明用于配置 SST-PB3-CLX-RLL 模块工作在从站 DP V0 模式下(遵循 DP 从站的规定,支持的数据长度为分别为 244 字节 I/O)。相关的 GSD 文件 (ssti0c44.gsd)可在 SST 软件安装目录下找到,具体路径可通过 SST Configuration Tool 从站目录中查找。



#### 工作原理:

上电后,模块引导固件(最新固件版本为7.26)至缓冲区并运行,OK指示 灯为常绿。CPU运行初始化程序,使模块工作于在线运行模式。同时,通过背 板总线设置模块的从站配置参数(Local:x:C.Data[16]-[23])。如果仅仅为从站模 式时,COMM通讯灯为灭。



#### 设置参数:

#### 主站: Siemens S7-400, CPU416-2(order number: 416-2\*K02-0AB0) 从站: SST-PB3-CLX-RLL

模式控制字: 3(从站模式) ←---→ Local:x:C.Data [16] 数据长度数值: 8 ←---→ Local:x:C.Data [17] 8 ←---→ Local:x:C.Data [18] 接收数据偏移区域: 100←---→ Local:x:C.Data [19] \*2) 发送数据偏移区域: 100←---→ Local:x:C.Data [20] \*2) 站号: 10 ←---→ Local:x:C.Data [21] 速率: 6 ←---→Local:x:C.Data [22] 中继器: 0 ←---→Local:x:C.Data [23] (无中继情况)

#### \*说明:

1) 有关从站配置可参考手册 P135-145 内容。如设置在**主从方式**下,模式控制值 需改为 1,此时若偏置设置为 0,从站接收和发送的数据自动放置在主站接收和 发送的数据区之后。模式控制: 1(主从站模式) ←---→ Local:3:C.Data [16]

2) 从站模式下,若未设置偏置值,数据直接映射在Local:x:I.Data [2] 和 Local:x:O.Data [2] 区内。

3)从站通讯速率设置值如下:

BAUD Rate	Register Value
BAUD_9k6	0
BAUD_19k2	1
BAUD_93k75	2
BAUD_187k5	3
BAUD_500k	4
BAUD_1m5	6
BAUD_3m	7
BAUD_6m	8
BAUD_12m	9
BAUD_31k25	10
BAUD_45k45	11

#### 设置步骤:

1) RSLOGIX5K 中设置 SST-PB3-CLX 模块属性。

Res Run	1 2 2 3 3 4 8 2 9 9 1 2 3 3 3 8 8 F
No Forces Controller OK No Edits I/O OK Redundancy D	Path:         AB_ETH-1\172. 16. 200. 210\Backplane\1*         Ed           Image: State of the
Controller SSTPFBCLX_Preview_2_E: Controller Tags Controller Fault Handler Fower-Up Handler Tasks FMainTask FMainTask FMainTask FMainTrogram FMotion Groups FVB_Dliagnostic_Read FVB_Origrouped Axes FVB_Origrouped Axes FVB_Strings FVB_	Lodule Properties - Local:3 (1756-LODULE 1.1)         General Connection Module Info Backplane         Type:       1756-MODULE Generic 1756 Module         Parent:       Local         Mame:       SST_FFB_CLX_Preview_1         Descrigtic       SST-FFB-CLX Preview-1         Descrigtic       SST-FFB-CLX Preview-1         Comm       Data - INT - With Status         Slgt:       3         Status:       Running         OK       Cancel

注意:从站模式下,配置寄存器必须配置为 24bytes 长度。

## 2) 配置寄存器 Local:x:C.Data [16] - [23]

+ Local:3:C.Data[9]	16#00		Hex	SINT
+ Local:3:C.Data[10]	16#00		Hex	SINT
+ Local:3:C.Data[11]	16#00		Hex	SINT
+ Local:3:C.Data[12]	16#00		Hex	SINT
+ Local:3:C.Data[13]	16#00		Hex	SINT
+ Local:3:C.Data[14]	16#00		Hex	SINT
+ Local:3:C.Data[15]	16#00		Hex	SINT
+ Local:3:C.Data[16]	16#03	从站模式	Hex	SINT
+ Local:3:C.Data[17]	16#08	8WORD 输	Hex	SINT
+ Local:3:C.Data[18]	16#08	人/输出	Hex	SINT
+ Local:3:C.Data[19]	16#64	偏移地址	Hex	SINT
+ Local:3:C.Data[20]	16#64	100	Hex	SINT
+ Local:3:C.Data[21]	16#0a	地址#10	Hex	SINT
+ Local:3:C.Data[22]	16#06	速率1.5∎bp	Hex	SINT
+ Local:3:C.Data[23]	16#00		Hex	SINT
+ Local:3:C.Data[24]	16#00		Hex	SINT

3) 输出数据区

输出数据可查看 Local:x:O.data [100] - [107] 数据区。

E-Local:3:0.Data[89]	0	Decimal	- 1
- Local:3:0.Data[90]	0	Decimal	I
-Local:3:0.Data[91]	0	Decimal	I
-Local:3:0.Data[92]	0	Decimal	I
-Local:3:0.Data[93]	0	Decimal	I
±-Local:3:0.Data[94]	0	Decimal	I
- Local:3:0.Data[95]	0	Decimal	I
-Local:3:0.Data[96]	0	Decimal	I
- Local:3:0.Data[97]	0	Decimal	I
± Local:3:0.Data[98]	0	Decimal	I
+ Local:3:0.Data[99]	0	Decimal	I
+ Local:3:0.Data[100]	l6#ffff	Hex	I
	l6#ffff	Hex	- 1
	16#dead	Hex	- 1
	l6#beaf	Hex	- 1
	16#1234	Hex	- 1
	16#2222	Hex	- 1
	16#5791	Hex	- 1
+-Local:3:0.Data[107]	16#1234	Hex	- 1
+ Local:3:0.Data[108]	0	Decimal	-

4) 输入数据可查看 Local:x:I.data [100] - [107] 数据区。

## 其它注意要点:

1) RSLogix5K 程序中需加入初始化程序(初始化程序按照设置的数据类型而定,可分为 SINT, INT, DINT 类型),具体可见安装目录:

A	Address 🛅 C:\Program Files\SST\Profibus\PFB\Ladder Sample Codes For ControlLogix			
		Name 🔺		
	File and Folder Tasks 🛛 🛠	BDPV1_ReadClass1.ACD		
	🔊 Bename this file	🔀 DPV1_ReadClass2.ACD		
		🚮 sstpfbclx IO Expansion.ACD		
	🔯 Move this file	🕵 sstpfbclx_preview_2_example.ACD		
	📄 Copy this file	sstpfbclx_preview_2_example.ACD_V11		
	🔕 Publish this file to the Web	👹 sstpfbclx_preview_2_example_DINT.ACD		
	🖄 E-mail this file	Sstpfbclx_preview_2_example_DINT_BAK000.acd		
	X Delete this file	Sstpfbclx_preview_2_example_SINT.ACD		

本例使用<SSTPFBCLX\_Preview\_2\_Example.ACD>文件。

2) 如模块设置在单从站模式下,需通过超级终端(通过串口,按\*键进入,注意: 如 RSLINX 有 DF1 串口驱动,需关闭),清除原模块可能存在的主站配置信息, 以使模块正常工作。相关命令为 showmas (显示 Master 配置信息)和 clrmas(清 除 Master 配置信息)。

毎秒位数 (B):	115200	*
数据位 (D):	8	*
奇偶校验 (2):	无	~
停止位 (S):	1	~
数据流控制 (2):	无	
	〔还原	为默认值 (2)

;Copyright (c) 1999-2002 SST/Woodhead Canada Ltd. ;For SST-PFB-CLX Card ;Version 4.07 Reading Configuration from FLASH...

;≻showmas DP Master Configuration:

TABLES IN THE STATE OF A STATE OF					Greek and the second second		S2007070707
MasBlk 0	\$lv\$ta	7 RxLen	10	0 TxLen	10	0 Slv Id	870
;>shownet							
Active	1						
LocStn	0						
Histn	126						
Baud	Tw2						
Repeater	0						
FMSUevices	0						
Stayutterr	0200						
SlotTime	007J 200						
TdloTimo1	37						
IdloTimo2	150						
RoaduTimo	11						
AuiTime	ă.						
GanUndFact	128						
TokRetrvl im	it 4						
MsaRetrvLim	it 4						
TokErrLimit	255						
RespErrLimi	t 15						
UserIdStr	PROFIE	BUS					

>clrmas Hre you sure you want to clear the DP Master configuration? (y/n)y Master Parameters Cleared ;>showmas DP Master Not Configured! ;>exit Configuration HAS CHANGED. Do You Want to UPDATE FLASH? (y/n)y Storing card configuration in FLASH... Card Configuration Stored in FLASH Successfully Exiting Comm Configuration....3) 当主站与本从站模块出现通讯故障时,除通过主站的诊断工具可以进行故障

排除外,推荐以下方法:

a) 监视DP Slave Status & Error Register(见手册P127 表格51/52),其中,状态信息可参考Local:x:S:Data[44].6和Local:x:S:Data[44].7。

Name	Location	Description
DP slave status bit 0 - 5	Local:Slot:S:Data[44].0 - 5	Reserved for future use
DP slave status SLV_STS_RUN_MODE bit	Local:Slot:S:Data[44].6	Set to True if the slave is being scanned by a remote master in "RUN" mode.
DP slave status SLV_STS_OK bit	Local:Slot:S:Data[44].7	Set to True if the current slave status is OK. This means parameterization was successful and the slave watchdog has not timed out.
DP slave error byte	Local:Slot:S:Data[44].8-15	The scanner sets the error byte to report various error conditions. If there are multiple errors, the register contains the value of the last error encountered.

# Table 51: DP Slave Status and Error Register

## Table 52: DP Slave Error Byte (Local:Slot:S:Data[44].8-15)

Error	Value	Description
SLV_ERR_ID_MISM	01h	Slave ID does not match the slave ID configured in the master. If there is a mismatch, the slave won't communicate with the master.
SLV_ERR_READY_TIME_MISM	02h	Ready time for the card is different from the value configured in the master. The card can communicate as a slave even if the times are different, but you may experience network errors.
SLV_ERR_UNSUP_REQ	03h	Master has requested Sync or Freeze during parameterization, which the card does not support.
SLV_ERR_RX_LEN_MISM	04h	Data received from the master has a length different from the length configured on the card. If there is a receive length mismatch, the card won't communicate as a slave.
SLV_ERR_TX_LEN_MISM	05h	Master has requested data from the slave with a length different from the length configured for the slave. If there is a transmit length mismatch, the card won't communicate as a slave.
SLV_ERR_WD_FACT_INV	06h	One of the two slave watchdog factors is zero, which is not allowed.
SLV_ERR_TIME_OUT	07h	Slave's watchdog timed out. The slave goes offline and must be reinitialized by the master.
SLV_ERR_WARN_WD_DIS	08h	Master has disabled the slave watchdog.